



RECORD TRACKS



TRACK ARMING

Select track to arm/unarm.
Not available during record or playback.
Button upper-left button: track name.
Button lower-left: track source .




TRACK SOURCE

Select track source using rotary encoder.
Not available during playback.
Button lower-left: track name.



TRACK NAME

View and edit all track names. Edition open the track name screen, which is also available in the metadata menu.
Button lower-left: track source.



TRACK COLOR

View and edit track colors.
Use the rotary encoder to select over the 8 available colors.

