


MENU SYSTEM




SYSTEM MENU

PUSH BUTTONS and MISC menus are not described in that page as they have a dedicated one.




CONFIG BACKUP/RESTORE

Allow to backup & restore current configuration (or part of it) into a SD card.
Select CREATE NEW to create a new configuration file, then choose a filename.
SAVE OPTIONS menu allow to choose configuration to store.




SAVE CONFIG

Allow user to save the recorder config.
Configuration is always saved every power down.




FILETAG

The filetag is an unique identifier automatically generating the audio WAV filenames.
The two letters can be freely modified by the user, which might be useful to identify the recorder unit or the production.
The 4 digits are automatically incremented each new take. When the number reaches 9999 it starts again to 0001 and the letters prefix is incremented to the next value (SX -> SY).
User can modify the 4 digits but the number must be at least greater than existing takes with identical letter prefix.




SYSTEM DATE

Set local date



SYSTEM TIME

Set local time and time zone.
If you don't know your time offset, visit https://en.wikipedia.org/wiki/List_of_UTC_time_offsets



SYSTEM INFO

Software revision and hardware status is displayed on that menu.
FACTORY SETTINGS button resets the recorder to factory settings, except for user settings and filetag.
SERVICE MENU spreads hardware and service information over multiple pages.

